
# MY/ROO MY OUTDOOR / ROO OUTDOOR







# MY/R00 MY OUTDOOR / R00 OUTDOOR







MINI-MY



#### **FABRICS**

Keeping fabrics clean keeps them looking better and improves their durability.
Upholstery fabrics should be cleaned at regular intervals. It is recommended to vacuum with

a textile nozzle at half the power weekly.

Vacuuming reduces pilling i.e. formation of lint on the fabrics surface.

Dry or damp cloth can also be used for cleaning fabrics with synthetic fibres.

Any dirt, whether solid or liquid, should be cleaned as quickly as possible.

Fixed dirt should first be removed carefully with a spatula or similar. Crumbs should be vacuumed prior to continuing the cleaning.

Liquid dirt must first be absorbed with an absorbent cloth.

Non-greasy stains are removed with a damp lint-free cloth or sponge. In order to prevent stain getting bigger, the cleaning movement should be from outer rim towards the center. Greasy stains should be removed with a suitable cleaning agent.

All cleaning agents should ALWAYS first be tested in an unnoticeable place before use on the entire product.

The instructions given here are for guidance only and do not necessarily guarantee the cleaning of the fabric. If necessary, we recommend seeking professional cleaning help.

### WASHING REMOVABLE COVERS

Certain fabrics can be washed with water. Please check washing instructions for particular fabrics from Price List or sample watches. Washing instructions for Adea's fabrics are also sewn in to the inside of the covers.

The covers should be washed with half-fill, colour wash dosage of and light spinning. Most domestic washing machines are too small for washing sofa covers. Overfilling the drum may cause damage to the machine as well as cause unsatisfactory washing result. We recommend using laundry services with larger machines for washing the covers.

The cover should be hanged for drying. Do not use tumble dryer.

The cover should be placed on top of the furniture lightly moist. When the fabric is moist, it is more elastic. Let the fabric dry completely before using the furniture.

## **ADEA COLLECTION FABRICS**

NAME	COMPOSITION	MAINTENANCE
ADEA LINEN	100% LI	
AURORA	45% PC, 19% CO, 12% LI, 12% VI, 12% PES	
AVALON	75% CO, 25%PC	
BARRY	70% VI, 30% LI	
BOHEMIAN	5% CO, 25% VI, 13% LI, 15% WO, 25%PES, 15%PC, 2%PA	
CALEIDO	63% CO, 37% LI	<u>₩</u> 🛦 🖾 🗇
DAS	50% PP, 31% PES, 19% CO	
DIAMONDS	46% PC, 44% PES, 10%C0	
DUMET	46% CO, 22% VI, 22%WO, 15%LI	
MALAWI	48% PC, 24% WO, 12% PES, 10% PA, 6% CO	
MARIGOLD	100% FR Polyester	₩ <b>★</b> 🖾 Æ 🕑
MATRIX	53% CO, 37%WO, 10%PA	
MEDEA	100% CO	
MELANGE	42% PP. 42% PES, 16% CO	
PANAMA LINEN	93% LI, 7% PA	
OPERA	100% CO	
ORIGIN	68% PP, 24% PES, 8%CO	
RICO	56% CO, 30% VI, 14% LI	
SAPPHIRE	100% PES	
STRAWBERRY THIEF	100% FR Polyester	₩ <u>*</u> 🖾 🗷 <u>®</u>
TAIGAL	64% CO, 10% LI, 20% VI, 6%PA	
TOSCANA	42% VI, 40% CO, 18% WO	
URUS	50% PP, 31% PES, 19% CO	₩ <b>X X X</b>

### ABBREVIATIONS

CO = Cotton

LI = Linen

PA = Nylon

PC = Acrylic

PES = Polyester PP = Polypropen VI = Viscose WO = Wool



Agent Austria

Frost International Rudolfsplatz 13a A 1010 Vienna Austria

s.bleil@frost-international.at +43 699 1505 5006 Showroom/Agent Benelux Union Flow Interior Gezondheidstraat 15 9000 Gent Belgium

info@flow-interior.be tel. +32 (0)486 357429

Showroom/Agent Sweden, Denmark & Norway Mobile Box AB Sibyllegatan 19 114 42 Stockholm Sweden

info@mobilebox.se tel. +46 8 422 83 88